

Product data sheet

Centre plate with knob for rotary switch



Reference number

SL 1541 WW

Centre plate with knob

for rotary switch insert ref.-no.: 1101-4, 1101-20

for timer switch insert ref.-no.: 11015, 11120-20

for rotary blind switch insert ref.-no.: 1234.10, 1234.20

also for volume control WHD type: LST..JU UP and LR..JU UP

and for program selection WHD type: PRO 3 JU..

Colour:

white

