

# Product data sheet

1-gang rocker with glass plate



Reference number
561 GL RT
<b>1-gang rocker with glass plate</b>
with rocker and red lens for all 1-gang switch/push-button inserts (except push switch insert)
With foils "Notschalter, Heizung, Rauchabzug, Lichtkuppel öffnen, Hausalarm, Bei Feuer Glas einschlagen – Knopf drücken"
<b>Spare glass plate</b> 64 x 53 x 1 mm: ref.-no. 60 GL <b>Spare foil</b> ref.-no. 60 FO <b>Frame 1-gang</b> red (similar RAL 3000): ref.-no. CD 581 GL RT
<b>Thermoplastic (breakproof) high-gloss</b>
<b>Colour:</b> red
<b>Version:</b> similar RAL 3000
<b>Material:</b> thermoplastic