


# Product data sheet

Rocker with arrow symbols for KNX push-button 2-gang



Reference number

CD 102 P

**2-gang rocker with arrow symbols**

for KNX push-button 2-gang ref.-no.: LS CD 10721 ST, LS CD 10921 ST, LS CD 10921 TE

**Duroplastic (scratch-proof) glossy**

**Colour:**  
ivory

**Material:**  
duroplastic

